

LVT

- *After installation, allow the adhesive to cure completely. The planks may be walked on immediately after installation, but should not be exposed to rolling loads until 72 hours after installation.*
- *Do not mop the floor for at least 5 days after installation. This will prevent excess moisture or cleaning agents from interfering with the adhesive curing.*
- *Use RamBoard, FloorShell, Cover Too or similar breathable flooring protection to protect the floor during any construction that goes on after installation. Tape the protection product to itself at the seams or to the wall-baseboard at the perimeter, but never to the flooring.*
- *Sweep or vacuum daily. Use only soft bristle attachments for vacuums.*
- *Place walk-off mats at all outside entrances to reduce the amount of dirt brought into the space. Do not use mats with a latex or rubber backing since these backings can cause permanent discoloration.*
- *Clean up spills and excessive liquids immediately.*
- *Damp mop as needed with water, or with a high-quality, pH-neutral vinyl cleaner such as Bona Pro Series Luxury Vinyl Floor Cleaner. Do not use solvent-based cleaners, waxes, oils, bleaches, abrasive cleaners, or products recommended for other types of flooring. Avoid any cleaners that describe themselves as a polish, 'rejuvenator,' or 'cleaner and polish in one.' Polishes can leave a residue that will dull the finish, collect dirt, and can be extremely difficult to remove.*
- *Do not use scouring powder products, steel wool, or abrasive cleaning implements on the floor.*

- *Use proper floor protection devices such as felt protectors under furniture to prevent scratching. Under desk chairs, protect the floor with a hard, solid mat. Rubber, carpet or other soft chair mats may allow indentations or other damage to the flooring.*
- *Avoid walking on your vinyl floors with cleats, sports shoes and high heels.*
- *Do not roll, drag or slide heavy objects across the floor. When moving heavy furniture, pick up the furniture completely and place it on a protective surface such as cardboard or plywood so that the furniture can be 'walked' along that surface.*
- *After installation, make sure that the flooring is never exposed to temperatures below 55°F (13°C) or above 85°F (30°C). Direct sunlight on flooring can produce surprisingly high temperatures. Window treatments may be necessary to protect the flooring from high heat.*